

The new command allows an ergonomic grip and gives the driver the certainty of controlling the accelerator while being able to hold the steering wheel with both hands.

A lever system positioned on the brake command allows freedom of movement in any condition and on any type of road, leaving the steering wheel free from any invasive devices.

In the standard version, it is supplied with a button for the brake lock, the horn and to restrict the speed. The latter memorises the position of the accelerator when driving.

By simply touching the lever, the memory is deleted and control becomes manual once more.

It is possible to install the brake lever and accelerator with a 6-service control unit to command lights, windscreen wipers and so on.

Community codes 25.04, 20.06, 35.01

Accelerator combined to the brake

evolution of the lever

